



Xcluder™ Pest Control Block Caps

Easy to Install Rodent Protection for Concrete/Cinder Block Walls

Use for Part #s: 162990



Installation Instructions -

No tools necessary for installation. We recommend using ordinary work gloves for handling the plated steel (edges can be sharp), and a quality landscape adhesive that is approved for use on block, stone, and timber construction (Titebond® PROvantage Landscape Adhesive, Loctite® PL® 500 Landscape Adhesive, or equivalent).

To install—

1. Place one bead of the adhesive at each corner of the first hole (See A above)
2. Place block cap so that the short end (B) of the cap goes towards the center of the brick and the longer/extended portion goes towards the next brick. The extended portion (C) is designed to cover the opening that is made when two bricks meet.

Two caps will be used for each block, the short ends will meet in the center, the long ends will extend towards the neighboring block. In some cases the block caps will overlap.

Four drops of adhesive is enough to permanently secure the Xcluder™ Block Caps into place.